

## TECHNOTE

### How to configure Fargo printers

---


**DATE:** May, 2019  
**AUTHOR:** Support

---

In this technote we can find the best configuration for the Fargo plugins on Bodno software.

We need first, to install the correct printer driver, and the printer should be online on the “Devices and Printers”

If we have a HDP or a DTC Fargo model, we need to set the plugin in the **Printer Drivers** according with the image bellow, under the “--V1--” to “**Fargo SDK**”.



Until the Fargo C50 model been fully implemented in Bodno, we need to set the plugin in the **Printer Drivers** according to the image bellow, under the "--V2--" to "**Generic Printer**".

Printer Model	Print Class
C50 Card Printer	<b>Generic Printer</b>

After the Fargo C50 to be fully implemented on Bodno, we will be able to use the same plugin as the others Fargo printers.

We need to restart the Bodno application to apply the changes after any plugin changes.

If further assistance is required, please don't hesitate to contact [support@Bodno.com](mailto:support@Bodno.com)